

# SterileLight™ CountDown™ PLUS Medical Grade Anti-Microbial Screen Protectors

Item# SL-CD-PLUS



**SterileLight™**  
"You're Safer with SterileLight"

Congratulations on your purchase of SterileLight CountDown Plus Medical Grade Anti-Microbial Screen Protectors! Our medical-grade film provides a critical extra step in protecting your frequently touched devices most prone to harmful pathogens.

You're in good company too. Here are just a few of the organizations that have implemented a SterileLight solution to reduce infection risk:



# Installing SterileLight™ Countdown™ PLUS Medical Grade Anti-Microbial Screen Protectors Item# SL-CD-PLUS

**IT IS CRUCIAL THAT YOU FOLLOW ALL INSTRUCTIONS TO GET A GOOD FILM INSTALLATION!!!**

**Not following the instructions correctly may result in trapped dirt that will appear as air bubbles under the film. Read the entire instruction set first before attempting to install the film. The film must be fully installed with both protective masks removed to function properly. Just placing the masked film against the screen will not work.**

Please note: We recommend that you wash your hands prior to installing the film.

**Step 1:** Your SterileLight anti-microbial film is masked on two sides. One mask covers the top surface and the other mask covers the tacky side.

**Step 2:** Make certain that your film fits the display. Lay the film into the display area to be certain that it is sized correctly. A small amount of *play* or gap on all sides to allow for easy installation is normal. If it does not fit correctly, do not attempt installation and contact us for instructions. If the film is larger than the screen and you wish to cut it, use sharp scissors.

**Step 3:** Clean the surface of your display with a damp, clean soft cloth. Wipe all areas of the screen, especially the edges and corners. Dry the screen with a soft dry cloth.

**NOTE:** If the film is larger than 12" diagonal, we recommend that two people install the film. One to hold the film steady and the other to slowly apply the film while pushing out air bubbles.

**Step 4:** Remove the mask covering the tacky side by using a piece of adhesive tape to stick to the mask. Pull back and remove this mask completely. You may have to try each side to find the tacky side. Once the back side is exposed, hold the film by the edges and position the exposed tacky side to the screen edge. Allow the film with the exposed back side to attach to the screen.

**Step 5:** Allow the exposed back side to adhere to the screen, using a finger to push air bubbles from the center to the edges. Be certain the film is properly aligned to the screen dimensions.

**Step 6:** Once you are happy with the installation, remove the mask film covering the top surface. Using a piece of adhesive tape, attach the tape firmly to a corner and lift to remove the top mask. You should now have a fully installed film. Air bubbles that will not move or edges that lift are likely dirt trapped under the film. Please see the Cleaning page for instructions on how to remove the dirt.

A video installation guide is also available at our website:

[https://sterilelight.com/prp\\_sl-cd-plus/](https://sterilelight.com/prp_sl-cd-plus/)



Clean the surface with a damp, clean soft cloth first and then dry thoroughly.



Hold the film by the masked area and place on display



Push out any remaining bubbles for complete fit of the film

# Cleaning SterileLight™ Countdown™ PLUS Medical Grade Anti-Microbial Screen Protectors

Item# SL-CD-PLUS

You can clean the top surface with any cleaner. If you notice that dust particles have gotten on the adhesive, they can be removed.

**Step 1:** Gently lift the corner of the Countdown PLUS anti-microbial film near the dust particle using a piece of adhesive tape or a fingernail being careful not to damage the backside of the film.

**Step 2:** Using a small piece of adhesive tape, gently touch the film with the tape to pick the dust particle off the tacky surface.

**Step 3:** To clean the entire back surface, remove the entire film and place it back side up.

**Step 4:** Using adhesive tape, lay the strips on top of the tacky surface, overlapping them as you add each one in succession until you have covered the entire side of the film with adhesive tape. Rub the adhesive tape against the film with a finger to ensure it will adhere to the dust particles.

**Step 5:** Once the entire surface is covered with tape, remove the tape quickly and it will remove all the dust particles with it.

**Step 6:** Return to Step 3 above if the screen needs to be cleaned again and reinstall the film as indicated on the previous page.



Lay adhesive tape over the particle and then pull back on tape to remove the particle



Sterile Light LLC  
Email:  
[info@sterilelight.com](mailto:info@sterilelight.com)  
Toll Free: 833-525-5550  
[sterilelight.com](http://sterilelight.com)

**SterileLight makes no Warranty, expressed or implied, on the suitability or performance of this product, except to replace product found to be defective. SterileLight assumes no liability for any damages that may result to other equipment due to the use, misuse of, or inability to use the product.**



SterileLight™

SL-AC-IDC-01

## ILLUMICIDE Medical Grade Anti-Microbial Panel Protector

When you place an item on the top, pathogens will be eradicated on the side of the item that contacts the anti-microbial surface. The Panel Protector is custom cut and is the same medical-grade anti-microbial film that's used in medical settings across the country, the same film used in our screen protectors for iPhones and iPads, and is the same film as our surface protection mats.

Please note: We recommend that you wash your hands prior to installing the panel protector.

The ILLUMICIDE medical grade anti-microbial panel protector is installed just as our Countdown Plus screen protectors are installed. A copy of this documentation and a link to an installation video can be found on our web site at the following link: [https://sterilelight.com/prp\\_sl-cd-plus/](https://sterilelight.com/prp_sl-cd-plus/)

Please position the film on the device as shown in the image below:



PLEASE NOTE: You'll periodically see small air bubbles appear which are easily worked out when pressed outward with the fingers (just as screen protectors for your phone). This occurs naturally due to button presses and objects being placed on the surface.