



ILLUMICIDE™ Surface Disinfecting Case (Beauty Edition) Quick Reference Guide



40 LED Array Provides 360° Disinfection



Disinfection Preserving Storage Mode Constant Temperature Drying



Dual Rechargeable Batteries Provide 60 Quick Disinfects



Intelligent Safety Design Shuts Off Automatically When Opened

Overview

SterileLight's **ILLUMICIDE** Disinfecting Case is a high-quality, professional-grade surface disinfection device.

Using mercury-free, eco-friendly germicidal light, it effectively reduces surface pathogens that can rapidly multiply on the surface of your cosmetic brushes, palettes, sponges and beauty tools in just 3 minutes (6 mins. for increased efficacy). (Quick Disinfect)



It has a built-in dryer for your cleaned/shampooed, sanitized and disinfected makeup brushes and tools. (Disinfect & Dry)

Disinfect items and keep them ready for use inside the storage case. Indicator light shows that items inside have been disinfected. (Disinfect & Store)



ILLUMICIDE™ Surface Disinfecting Case (Beauty Edition) Quick Reference Guide

SterileLight™

SL-UVC-IDC-01-B

3 Operating Modes

1 Quick Disinfect (clean/sanitize items prior to disinfecting)



Press for 3 Minute Quick Disinfection Cycle (180 seconds)
Battery or AC Power

2 Disinfect & Dry



Press for 3 Minute Disinfection Cycle (180 seconds) followed by a 30, 60, or 90 minute Smart Drying Cycle. Once complete, device enters Disinfect & Store mode.
AC Power Required

3 Disinfect & Store



Press for 3 Minute Disinfection Cycle (180 seconds) AND ongoing Disinfection Preservation Cycles.
AC Power Required

5 LED Counter



Displays the number of seconds or minutes remaining in the cycle for the selected function

7 Stainless Steel Tray



Supports items to be disinfected and raises them above the reflective base of the device.



Note: Reactor will fade to white within 15 seconds. Not recommended for use during drying cycle as it may reduce reactor effectiveness.



NOTE: Upon receipt of the device, please charge overnight.

4 ON/OFF Button



Press to power the device ON or OFF

6 OPEN Button



Opens the device cover and initiates the auto shut-off safety feature.

8 Power Receptacle



USB-C transformer power receptacle. Use for charging device, Disinfect & Dry, and Disinfect & Store



Power receptacle is located in the lower center on the back of the device.



SterileLight™

SL-AC-IDC-01

If you added the Anti-Microbial Panel Protector...

Then congratulations on your purchase of SterileLight's CountDown Plus medical-grade Anti-microbial Panel Protector for your ILLUMICIDE Disinfecting Case. You've now joined a growing community that have the additional peace of mind gained by a germ and bacteria free surface to place your beauty items on while you work.





SterileLight™

SL-AC-IDC-01

ILLUMICIDE Medical Grade Anti-Microbial Panel Protector

When you place an item on the top, pathogens will be eradicated on the side of the item that contacts the anti-microbial surface. The Panel Protector is custom cut and is the same medical-grade anti-microbial film that's used in medical settings across the country, the same film used in our screen protectors for iPhones and iPads, and is the same film as our surface protection mats.

Note: Please wash your hands prior to installing the screen protector.

The ILLUMICIDE anti-microbial panel protector is installed just as our Countdown Plus screen protectors are installed. There is an installation guide link as well as an installation video on our web site at the following link:

https://sterilelight.com/prp_sl-cd-plus/

Please position the film on the device as shown in the image below:



PLEASE NOTE: You'll periodically see small air bubbles appear which are easily worked out when pressed outward with the fingers (just as screen protectors for your phone). This occurs naturally due to button presses and objects being placed on the surface.